

Screenshot mobilnih telefona

Pre verzije 4.0 Android nije imao mogućnosti snimanja ekrana ako je proizvođači uređaja nisu omogućili, a za verziju 4.0 i noviju to je kombinacija **Power** tastera i **Volume Down** (smanjivanje zvuka) tastera.

<p>Samsung</p> <p>Ne drži tog standarda Androida, nego je kombinacija Power i Home tastera kao što je kod Apple uređaja.</p>	 A Samsung smartphone is shown from a front-on perspective. The screen displays the time as 12:45 and the date as Tue, 1 September. Two red arrows point to specific buttons: one arrow points to the power button located on the right side of the phone, and another arrow points to the home button located at the bottom center of the device.
---	--


Windows Phone

Različito za Win Phone 8 i 8.1. U WP 8 je potrebno u isto vreme pritisnuti **Power** taster i **Start** taster, a kod WP 8.1 je kombinacija **Power** plus **Power Up** (pojačavanje zvuka). To su Microsoft telefoni ili Nokia je nekad pisalo.





iPhone

potrebno je u isto vreme pritisnuti **Power** (taster za paljenje) i **Home**



Huawei

Koristi se dugme **Power + Volume own**. Druga mogućnost je kada se spusti navigaciona table I tu ima opcija za snimanje ekrana.



LG

Ne drže se iste kombinacije kod svakog modela telefona, tako da postoji mogućnost na jednom LG modelu da je kombinacija **Power + Home**, a na drugom **Power + Volume Down**.



Lenovo

Koristi se dugme **Power + Volume Down**.



Alcatel

Koristi se dugme **Power + Volume Down**.



Tesla

Pritisnite dugme **Power** i okrugli **Home** taster koji se nalazi na prednjoj strani. Kod nekih telefona samo prevučete tri prsta zajedno od vrha do dna ekrana.



Vredi napomenuti da neki proizvođači dodaju opciju snimanja ekrana u **Power meni** (pojavljuje se kada zadržite Power dugme nekoliko sekundi), ali to nije pravilo.